

## 

- To activate the upgrade, the license file is simply transferred to the sensor using the nVision-i Start interface.
- The serial number of the device is required for the license creation. Please enter the serial number in the comment field when placing your order.



Function	
	CE CH Z
Technical data (typ.)	
Model	Upgrade
To be used for	CS 60 Vision Sensors, ID-600 Fixed-mounted ID Reader
More information / accessories	https://www.di-soric.com/214845