

ID-SYSTEM

ID-110



800012-000000 · Rev 1 · 202008

CONFIGURATION GUIDE

 **di-soric**

Table of content

Bluetooth Settings	7
Bluetooth Radio Disconnect (Reconnect via Quick Connect Barcode)	7 (A2)
Bluetooth Auto Reconnect On - Default	7 (A3)
Bluetooth Auto Reconnect Off	7 (A4)
Bluetooth Radio Out of Range Beep On	7 (B1)
Bluetooth Radio Out of Range Beep and Vibrate Off - Default	7 (B2)
Bluetooth Radio Out of Range Beep and Vibrate On	7 (B3)
Bluetooth Radio Out of Range Vibrate On	7 (B4)
Bluetooth® HID Keyboard Mode	7 (C1)
Enable SPP Discoverable Mode	7 (C2)
Disable SPP Discoverable Mode - Default	7 (C3)
Bluetooth® Serial Port Profile (SPP) Mode	7 (C4)
Batch Mode Settings	7-8
Batch Mode Disable - Default	7 (D2)
Batch Mode Enable - Log Only	7 (D3)
Batch Mode Enable - Send and Log	7 (D4)
Batch Mode Auto Transfer Buffer Memory On	7 (E1)
Batch Mode Auto Transfer Buffer Memory Off	7 (E2)
Batch Mode Transfer All Data and Images in Memory	7 (E3)
Batch Mode Transfer Only Unsent Data in Memory	7 (E4)
Delete Buffered Scan Data	8 (A1)
USB Keyboard Mode - Batch Mode Only	8 (A2)
USB Virtual COM One Way Mode	8 (A3)
USB Speed High Speed - Batch Mode Only - Default	8 (A4)
USB Speed Full Speed - Batch Mode Only	8 (B1)
General Modem Settings	8
Preemptive Mode On	8 (B3)
Preemptive Mode Off - Default	8 (B4)
Reader Paging On - Default	8 (C1)
Reader Paging Off	8 (C2)
General Reading Mode Settings	8-9
Continuous Scan On	8 (C4)
Continuous Scan Off - Default	8 (D1)
Mountable Palm Charger Motion Detection - On	8 (D2)
Mountable Palm Charger Motion Detection - Off	8 (D3)
Anti-Glare On	8 (D4)
Anti-Glare Off - Default	8 (E1)
Mirroring On	8 (E2)
Mirroring Off - Default	8 (E3)
Targeting On - Default	8 (E4)
Targeting Off	9 (A1)
Cell Phone Reading Enhancement On	9 (A2)
Cell Phone Reading Enhancement Off - Default	9 (A3)
Data Formatting (Prefix/Suffix) Settings	9-10
Turn on Timestamp Prefix	9 (B2)
Turn off Timestamp Prefix - Default	9 (B3)
Convert output to lowercase	9 (B4)
Erase Prefix & Suffix Data - Default	9 (C1)
Erase Prefix Data - Default	9 (C2)
Erase Suffix Data - Default	9 (C3)
Prefix AIM.ID On	9 (C4)
Prefix AIM.ID Off - Default	9 (D1)
Prefix Carriage Return Line Feed (RS232 Mode Only)	9 (D2)
Prefix Comma	9 (D3)
Prefix Space	9 (D4)

Prefix Tab (USB Keyboard Mode Only)	9 (E1)
Prefix Tab (RS232 Mode Only)	9 (E2)
Suffix Carriage Return (RS232 Mode Only)	9 (E3)
Suffix Carriage Return Line Feed (RS232 Mode Only)	9 (E4)
Suffix Comma	10 (A1)
Suffix Enter (USB Keyboard Mode Only)	10 (A2)
Suffix Line Feed (RS232 Mode Only)	10 (A3)
Suffix Space	10 (A4)
Suffix Tab (USB Keyboard Mode Only)	10 (B1)
Suffix Tab (RS232 Mode Only)	10 (B2)
Translate all Characters to Uppercase On	10 (B3)
Translate all Characters to Uppercase Off - Default	10 (B4)

Symbology Settings **10-17**

Australian Post On	10 (C2)
Australian Post Off - Default	10 (C3)
Aztec On - Default	10 (C4)
Aztec Inverse On	10 (D1)
Aztec Inverse & Normal On	10 (D2)
Aztec Off	10 (D3)
Codabar On - Default	10 (D4)
Codabar Off	10 (E1)
Remove Codabar Start and Stop Delimiters	10 (E2)
Keep Codabar Start and Stop Delimiters - Default	10 (E3)
Codablock F On	10 (E4)
Codablock F Off - Default	11 (A1)
Code 11 On	11 (A2)
Code 11 Off - Default	11 (A3)
Code 11 Checksum Stripped from Result On	11 (A4)
Code 32 (Italian Pharmacode) On	11 (B1)
Code 32 (Italian Pharmacode) Off - Default	11 (B2)
Code 39 Off	11 (B3)
Code 39 On - Default	11 (B4)
Code 39 Checksum On	11 (C1)
Code 39 Checksum Off - Default	11 (C2)
Code 39 Checksum Stripped from Result On	11 (C3)
Code 39 Extended Full ASCII Off - Default	11 (C4)
Code 39 Extended Full ASCII On	11 (D1)
Code 49 On	11 (D2)
Code 49 Off - Default	11 (D3)
Code 93 On - Default	11 (D4)
Code 93 Off	11 (E1)
Code 128 On - Default	11 (E2)
Code 128 Off	11 (E3)
Composite On	11 (E4)
Composite Off - Default	12 (A1)
Data Matrix Inverse On - Default	12 (A2)
Data Matrix Inverse Off	12 (A3)
Data Matrix Rectangular On & Rectangular Extended On	12 (A4)
Data Matrix Rectangular On & Rectangular Extended Off - Default	12 (B1)
Data Matrix Rectangular & Rectangular Extended Off	12 (B2)
Grid Matrix On	12 (B3)
Grid Matrix Off - Default	12 (B4)
All GS1 DataBar On - Default	12 (C1)
All GS1 DataBar Off	12 (C2)
GS1 DataBar Limited On	12 (C3)
GS1 DataBar Limited Off	12 (C4)
GS1 DataBar Expanded On	12 (D1)

GS1 DataBar Expanded Off	12 (D2)
GS1 DataBar Expanded Stacked On	12 (D3)
GS1 DataBar Expanded Stacked Off	12 (D4)
GS1 DataBar Stacked and GS1 DataBar Stacked Omnidirectional On	12 (E1)
GS1 DataBar Stacked and GS1 DataBar Stacked Omnidirectional Off	12 (E2)
GS1 DataBar Omnidirectional and GS1 DataBar Truncated On	12 (E3)
GS1 DataBar Omnidirectional and GS1 DataBar Truncated Off	12 (E4)
Han Xin On	13 (A1)
Han Xin Off - Default	13 (A2)
Hong Kong 2 of 5 Off - Default	13 (A3)
Hong Kong 2 of 5 On	13 (A4)
Int 2 of 5 On - Default	13 (B1)
Int 2 of 5 Off	13 (B2)
Int 2 of 5 Checksum Stripped from Result On	13 (B3)
Int 2 of 5 Checksum On	13 (B4)
Int 2 of 5 Checksum Off - Default	13 (C1)
Japan Post On	13 (C2)
Japan Post Off - Default	13 (C3)
KIX (Dutch Post) Code On	13 (C4)
KIX (Dutch Post) Code Off - Default	13 (D1)
Korean Post On	13 (D2)
Korean Post Off - Default	13 (D3)
Maxicode On	13 (D4)
Maxicode Off - Default	13 (E1)
Matrix 2 of 5 On	13 (E2)
Matrix 2 of 5 Off - Default	13 (E3)
Micro PDF417 On	13 (E4)
Micro PDF417 Off - Default	14 (A1)
MSI Plessey On	14 (A2)
MSI Plessey Off - Default	14 (A3)
NEC 2 of 5 On	14 (A4)
NEC 2 of 5 Off - Default	14 (B1)
PDF417 On - Default	14 (B2)
PDF417 Off	14 (B3)
Pharmacode On	14 (B4)
Pharmacode Reverse Barcode Decoding (Right to Left)	14 (C1)
Pharmacode Normal Barcode Decoding (Left to Right)	14 (C2)
Pharmacode Off - Default	14 (C3)
All QR Code On	14 (C4)
Standard QR Code On - Default	14 (D1)
All QR Code Off	14 (D2)
Straight 2 of 5 On	14 (D3)
Straight 2 of 5 Off - Default	14 (D4)
Telepen On	14 (E1)
Output Telepen as ASCII	14 (E2)
Output Telepen as Numeric - Default	14 (E3)
Telepen Off - Default	14 (E4)
Trioptic On	15 (A1)
Trioptic - Enable Reverse Order option (Bit 3)	15 (A2)
Trioptic - Disable Reverse Order option (Bit 3) - Default	15 (A3)
Trioptic Off - Default	15 (A4)
UK Plessey On	15 (B1)
UK Plessey Off - Default	15 (B2)
UK Royal Mail On	15 (B3)
UK Royal Mail Off - Default	15 (B4)
UPC Off	15 (C1)
UPC On - Default	15 (C2)
UPC Supplemental On	15 (C3)

Transmit UPC-A Number System Off	15 (C4)
UPC Supplemental Off - Default	15 (D1)
Transmit UPC-A Check Digit On - Default	15 (D2)
Transmit UPC-A Check Digit Off	15 (D3)
Transmit UPC-A Number System On - Default	15 (D4)
Convert UPC-A to EAN-13 On	15 (E1)
Convert UPC-A to EAN-13 Off - Default	15 (E2)
UPC-E Expansion On	15 (E3)
UPC-E Expansion Off - Default	15 (E4)
Transmit UPC-E Check Digit On - Default	16 (A1)
Transmit UPC-E Check Digit Off	16 (A2)
Transmit UPC-E Number System On - Default	16 (A3)
Transmit UPC-E Number System Off	16 (A4)
Transmit EAN-8 Check Digit On - Default	16 (B1)
Transmit EAN-8 Check Digit Off	16 (B2)
Convert EAN-8 to EAN-13 On	16 (B3)
Convert EAN-8 to EAN-13 Off - Default	16 (B4)
Transmit EAN-13 Check Digit On - Default	16 (C1)
Transmit EAN-13 Check Digit Off	16 (C2)
Convert Bookland EAN-13 to ISBN On	16 (C3)
Convert Bookland EAN-13 to ISBN Off - Default	16 (C4)
Convert Bookland EAN-13 to ISSN On	16 (D1)
Convert Bookland EAN-13 to ISSN Off - Default	16 (D2)
UPU ID-Tag On	16 (D3)
UPU ID-Tag Off - Default	16 (D4)
USPS Intelligent Mail/IMB/ 4-State CB On	16 (E1)
USPS Intelligent Mail/IMB/ 4-State CB Off - Default	16 (E2)
USPS Planet On	16 (E3)
USPS Planet Off - Default	16 (E4)
USPS Postnet On	17 (A1)
USPS Postnet Off - Default	17 (A2)
Grid Matrix & Grid Matrix Inverse Decoding On	17 (A3)
Grid Matrix & Grid Matrix Mirror Decoding On	17 (A4)
Grid Matrix, Grid Matrix Inverse & Grid Matrix Mirror Decoding	17 (B1)
GoCode & GoCode Inverse Decoding	17 (B2)
GoCode & GoCode Mirror Decoding On	17 (B3)
GoCode, GoCode Inverse & GoCode Mirror Decoding On	17 (B4)
Code 11 Decoding with one checksum digit checked, and remove checksum from output On	17 (C1)



















Keyboard Language Settings **17-18**



















Keyboard Support: French Keyboard Mapping for Apple	17 (C3)
Keyboard Support: USInternational (Universal) Keyboard Mapping for Windows	17 (C4)
English (US) Keyboard Mapping for Windows	17 (D1)
English (UK) Keyboard Mapping for Windows	17 (D2)
Belgian French Keyboard Mapping for Windows	17 (D3)
French Keyboard Mapping for Windows	17 (D4)
German Keyboard Mapping for Windows	17 (E1)
Japanese Keyboard Mapping for Windows	17 (E2)
Latin American Keyboard Mapping for Windows	17 (E3)
Spanish Keyboard Mapping for Windows	17 (E4)
Swiss German Keyboard Mapping for Windows	18 (A1)
English Keyboard Mapping for Apple	18 (A2)
Keyboard Support: Spanish Keyboard Mapping for Apple	18 (A3)
Italian Keyboard Mapping for Apple	18 (A4)
German-Swiss Keyboard Mapping for Apple	18 (B1)
German Keyboard Mapping for Apple	18 (B2)
Russian Keyboard Mapping for Windows	18 (B3)
Control Character Input - Ctrl + Character	18 (B4)









Control Character Input - Alt + Keypad	18 (C1)
Control Character Input -Alt + Leading Zero	18 (C2)
Control Character Input - Language - Default	18 (C3)
Data Encoding: Raw ASCII to Keyboard XML File Lookup - Default	18 (C4)
Data Encoding: UTF8 to Unicode Codepoint - Alt Sequences for Windows	18 (D1)
Reader (Legacy) - US English Keyboard Mapping - with Leading 0 for Non Printable ASCII - Default	18 (D2)
Operating System Settings	18
Alternative Operating System (Linux/Mac) On	18 (D4)
Alternative Operating System (Linux/Mac) Off - Default	18 (E1)
USB Settings (Non-Batch Mode)	18-19
Modem - USB Keyboard Communication Mode - Default	18 (E3)
USB Downloader Mode	18 (E4)
Modem - USB HID POS	19 (A1)
Modem - USB Virtual COM Mode	19 (A2)
USB Settings	19
Reader - USB Virtual COM CDC Raw Mode	19 (A4)
RS232 Settings (for use with CodeXML M3 Modem Only)	19
RS232 Communication Mode	19 (B2)
RS232 Interface - 9600 Baud Rate - Default	19 (B3)
RS232 Interface - 19200 Baud Rate	19 (B4)
RS232 Interface - 38400 Baud Rate	19 (C1)
RS232 Interface - 57600 Baud Rate	19 (C2)
RS232 Interface - 115200 Baud Rate	19 (C3)
RS232 Settings	19
Reader - Enable RS232 OPOS/JPOS	19 (D2)
Reader Feedback Settings	19-20
Beep On Vibrate On - Default	19 (D4)
Beep Off Vibrate Off	19 (E1)
Beep Off Vibrate On	19 (E2)
Beep On Vibrate Off	19 (E3)
Disable AES Encryption - Default	19 (E4)
Beep Volume 100% - Default	20 (A1)
Beep Volume 67%	20 (A2)
Beep Volume 33%	20 (A3)
Beep Volume 0%	20 (A4)
Scan Delay Settings	20
Duplicate Scan Disabled - Default	20 (B2)
1 Second Duplicate Scan Delay	20 (B3)
2 Second Duplicate Scan Delay	20 (B4)
3 Second Duplicate Scan Delay	20 (C1)
5 Second Duplicate Scan Delay	20 (C2)
10 Second Duplicate Scan Delay	20 (C3)
30 Second Duplicate Scan Delay	20 (C4)
1 Hour Duplicate Scan Delay	20 (D1)
1 Day Duplicate Scan Delay	20 (D2)
Power Settings	20
Power Off in 1 Hour	20 (D4)
Power Off in 2 Hour	20 (E1)
Power Off in 4 Hours	20 (E2)
Miscellaneous Settings	20-21
Read Both Wide and High Density Field - Default	20 (E4)
Read High Density Field Only	21 (A1)


Read Wide Field Only	21 (A2)
Enable AES Encryption	21 (A3)
Bottom Button Take Picture	21 (A4)
Top Button Take Picture	21 (B1)
Locked Reader Accept Host Commands - Default	21 (B2)
Locked Reader Reject Host Commands	21 (B3)
Allow Wireless Switching on a Locked Reader - Default	21 (B4)
Prevent Wireless Switching on a Locked Reader	21 (C1)
Reader/Modem Command Settings	21
Reader ID and Firmware Version	21 (C3)
Modem ID and Firmware Version	21 (C4)
Reader Text Commands On	21 (D1)
Reader Text Commands Off - Default	21 (D2)
Reset, Clear and Save Reader Settings	21
Reset Reader to RF Factory Defaults	21 (D4)
Clear All JavaScript Rules	21 (E1)
Clear All Stored Data and Images	21 (E2)
Save All Reader Settings - Default	21 (E3)
Reboot Reader	21 (E4)

Notes on open source software	23
-------------------------------	----




ID-110 Configuration Guide		NOTE: Configuration changes will take effect immediately and be saved to memory.	
Bluetooth Settings	<p>Bluetooth Radio Disconnect (Reconnect via Quick Connect Barcode)</p>  <p>M10177_01</p> <p style="text-align: right;">A2</p>	<p>Bluetooth Auto Reconnect On - Default</p>  <p>M10365_01</p> <p style="text-align: right;">A3</p>	<p>Bluetooth Auto Reconnect Off</p>  <p>M10364_01</p> <p style="text-align: right;">A4</p>
<p>Bluetooth Radio Out of Range Beep On</p>  <p>M10173_01</p> <p style="text-align: right;">B1</p>	<p>Bluetooth Radio Out of Range Beep and Vibrate Off - Default</p>  <p>M10176_01</p> <p style="text-align: right;">B2</p>	<p>Bluetooth Radio Out of Range Beep and Vibrate On</p>  <p>M10175_01</p> <p style="text-align: right;">B3</p>	<p>Bluetooth Radio Out of Range Vibrate On</p>  <p>M10174_01</p> <p style="text-align: right;">B4</p>
<p>Bluetooth® HID Keyboard Mode</p>  <p>M10519_01</p> <p style="text-align: right;">C1</p>	<p>Enable SPP Discoverable Mode</p>  <p>M10542_02</p> <p style="text-align: right;">C2</p>	<p>Disable SPP Discoverable Mode - Default</p>  <p>M10543_01</p> <p style="text-align: right;">C3</p>	<p>Bluetooth® Serial Port Profile (SPP) Mode</p>  <p>M10518_01</p> <p style="text-align: right;">C4</p>
Batch Mode Settings	<p>Batch Mode Disable - Default</p>  <p>M10187_04</p> <p style="text-align: right;">D2</p>	<p>Batch Mode Enable - Log Only</p>  <p>M10188_04</p> <p style="text-align: right;">D3</p>	<p>Batch Mode Enable - Send and Log</p>  <p>M10186_05</p> <p style="text-align: right;">D4</p>
<p>Batch Mode Auto Transfer Buffer Memory On</p>  <p>M10307_01</p> <p style="text-align: right;">E1</p>	<p>Batch Mode Auto Transfer Buffer Memory Off</p>  <p>M10308_01</p> <p style="text-align: right;">E2</p>	<p>Batch Mode Transfer All Data and Images in Memory</p>  <p>M10297_01</p> <p style="text-align: right;">E3</p>	<p>Batch Mode Transfer Only Unsent Data in Memory</p>  <p>M10305_01</p> <p style="text-align: right;">E4</p>





















ID-110 Configuration Guide			NOTE: Configuration changes will take effect immediately and be saved to memory.	
<p>Delete Buffered Scan Data</p>  <p>M10306_01</p> <p>A1</p>	<p>USB Keyboard Mode - Batch Mode Only</p>  <p>M10200_01</p> <p>A2</p>	<p>USB Virtual COM One Way Mode</p>  <p>M10005_01</p> <p>A3</p>	<p>USB Speed High Speed - Batch Mode Only - Default</p>  <p>M10160_01</p> <p>A4</p>	
<p>USB Speed Full Speed - Batch Mode Only</p>  <p>M10161_01</p> <p>B1</p>	<p>General Modem Settings</p>		<p>Preemptive Mode On</p>  <p>M10225_02</p> <p>B3</p>	<p>Preemptive Mode Off - Default</p>  <p>M10226_02</p> <p>B4</p>
<p>Reader Paging On - Default</p>  <p>M10155_01</p> <p>C1</p>	<p>Reader Paging Off</p>  <p>M10156_01</p> <p>C2</p>	<p>General Reading Mode Settings</p>		<p>Continuous Scan On</p>  <p>M10012_02</p> <p>C4</p>
<p>Continuous Scan Off - Default</p>  <p>M10011_01</p> <p>D1</p>	<p>Mountable Palm Charger Motion Detection - On</p>  <p>M10373_01</p> <p>D2</p>	<p>Mountable Palm Charger Detection - Off Motion</p>  <p>M10374_02</p> <p>D3</p>	<p>Anti-Glare On</p>  <p>M10352_01</p> <p>D4</p>	
<p>Anti-Glare Off - Default</p>  <p>M10433_01</p> <p>E1</p>	<p>Mirroring On</p>  <p>M10125_01</p> <p>E2</p>	<p>Mirroring Off - Default</p>  <p>M10124_02</p> <p>E3</p>	<p>Targeting On - Default</p>  <p>M10153_01</p> <p>E4</p>	





















ID-110 Configuration Guide			NOTE: Configuration changes will take effect immediately and be saved to memory.
<p>Targeting Off</p>  <p>M10154_01</p> <p>A1</p>	<p>Cell Phone Reading Enhancement On</p>  <p>M10163_01</p> <p>A2</p>	<p>Cell Phone Reading Enhancement Off - Default</p>  <p>M10162_01</p> <p>A3</p>	<p>Intentionally Blank</p> <p>A4</p>
<p>Data Formatting (Prefix/Suffix) Settings</p>	<p>Turn on Timestamp Prefix</p>  <p>M10342_01</p> <p>B2</p>	<p>Turn off Timestamp Prefix - Default</p>  <p>M10343_02</p> <p>B3</p>	<p>Convert output to lowercase</p>  <p>M10439_01</p> <p>B4</p>
	<p>Erase Prefix & Suffix Data - Default</p>  <p>M10135_01</p> <p>C1</p>	<p>Erase Prefix Data - Default</p>  <p>M10126_01</p> <p>C2</p>	<p>Erase Suffix Data - Default</p>  <p>M10130_01</p> <p>C3</p>
<p>Prefix AIM ID Off - Default</p>  <p>M10198_01</p> <p>D1</p>	<p>Prefix Carriage Return Line Feed (RS232 Mode Only)</p>  <p>M10405_01</p> <p>D2</p>	<p>Prefix Comma</p>  <p>M10127_01</p> <p>D3</p>	<p>Prefix Space</p>  <p>M10128_01</p> <p>D4</p>
<p>Prefix Tab (USB Keyboard Mode Only)</p>  <p>M10129_01</p> <p>E1</p>	<p>Prefix Tab (RS232 Mode Only)</p>  <p>M10319_01</p> <p>E2</p>	<p>Suffix Carriage Return (RS232 Mode Only)</p>  <p>M10320_01</p> <p>E3</p>	<p>Suffix Carriage Return Line Feed (RS232 Mode Only)</p>  <p>M10322_01</p> <p>E4</p>

ID-110 Configuration Guide				NOTE: Configuration changes will take effect immediately and be saved to memory.
<p>Suffix Comma</p>  <p>M10131_01</p> <p>A1</p>	<p>Suffix Enter (USB Keyboard Mode Only)</p>  <p>M10134_01</p> <p>A2</p>	<p>Suffix Line Feed (RS232 Mode Only)</p>  <p>M10321_01</p> <p>A3</p>	<p>Suffix Space</p>  <p>M10132_01</p> <p>A4</p>	
<p>Suffix Tab (USB Keyboard Mode Only)</p>  <p>M10133_01</p> <p>B1</p>	<p>Suffix Tab (RS232 Mode Only)</p>  <p>M10323_01</p> <p>B2</p>	<p>Translate all Characters to Uppercase On</p>  <p>M10229_03</p> <p>B3</p>	<p>Translate all Characters to Uppercase Off - Default</p>  <p>M10426_02</p> <p>B4</p>	
<p>Symbology Settings</p>	<p>Australian Post On</p>  <p>M10288_02</p> <p>C2</p>	<p>Australian Post Off - Default</p>  <p>M10289_02</p> <p>C3</p>	<p>Aztec On - Default</p>  <p>M10018_01</p> <p>C4</p>	
<p>Aztec Inverse On</p>  <p>M10020_01</p> <p>D1</p>	<p>Aztec Inverse & Normal On</p>  <p>M10021_01</p> <p>D2</p>	<p>Aztec Off</p>  <p>M10019_01</p> <p>D3</p>	<p>Codabar On - Default</p>  <p>M10022_01</p> <p>D4</p>	
<p>Codabar Off</p>  <p>M10023_01</p> <p>E1</p>	<p>Remove Codabar Start and Stop Delimiters</p>  <p>M10537_01</p> <p>E2</p>	<p>Keep Codabar Start and Stop Delimiters - Default</p>  <p>M10538_01</p> <p>E3</p>	<p>Codablock F On</p>  <p>M10027_01</p> <p>E4</p>	

ID-110 Configuration Guide				NOTE: Configuration changes will take effect immediately and be saved to memory.
<p>Codablock F Off - Default</p>  <p>M10026_01</p> <p style="text-align: right;">A1</p>	<p>Code 11 On</p>  <p>M10029_02</p> <p style="text-align: right;">A2</p>	<p>Code 11 Off - Default</p>  <p>M10028_02</p> <p style="text-align: right;">A3</p>	<p>Code 11 Checksum Stripped from Result On</p>  <p>M10031_02</p> <p style="text-align: right;">A4</p>	
<p>Code 32 (Italian Pharmacode) On</p>  <p>M10239_02</p> <p style="text-align: right;">B1</p>	<p>Code 32 (Italian Pharmacode) Off - Default</p>  <p>M10238_02</p> <p style="text-align: right;">B2</p>	<p>Code 39 Off</p>  <p>M10054_02</p> <p style="text-align: right;">B3</p>	<p>Code 39 On - Default</p>  <p>M10035_02</p> <p style="text-align: right;">B4</p>	
<p>Code 39 Checksum On</p>  <p>M10036_01</p> <p style="text-align: right;">C1</p>	<p>Code 39 Checksum Off - Default</p>  <p>M10035_01</p> <p style="text-align: right;">C2</p>	<p>Code 39 Checksum Stripped from Result On</p>  <p>M10037_01</p> <p style="text-align: right;">C3</p>	<p>Code 39 Extended Full ASCII Off - Default</p>  <p>M10038_01</p> <p style="text-align: right;">C4</p>	
<p>Code 39 Extended Full ASCII On</p>  <p>M10039_01</p> <p style="text-align: right;">D1</p>	<p>Code 49 On</p>  <p>M10458_01</p> <p style="text-align: right;">D2</p>	<p>Code 49 Off - Default</p>  <p>M10459_01</p> <p style="text-align: right;">D3</p>	<p>Code 93 On - Default</p>  <p>M10042_01</p> <p style="text-align: right;">D4</p>	
<p>Code 93 Off</p>  <p>M10043_01</p> <p style="text-align: right;">E1</p>	<p>Code 128 On - Default</p>  <p>M10044_01</p> <p style="text-align: right;">E2</p>	<p>Code 128 Off</p>  <p>M10045_01</p> <p style="text-align: right;">E3</p>	<p>Composite On</p>  <p>M10047_02</p> <p style="text-align: right;">E4</p>	

ID-110 Configuration Guide				NOTE: Configuration changes will take effect immediately and be saved to memory.
<p>Composite Off - Default</p>  <p>M10046_01</p> <p>A1</p>	<p>Data Matrix Inverse On - Default</p>  <p>M10051_03</p> <p>A2</p>	<p>Data Matrix Inverse Off</p>  <p>M10059_03</p> <p>A3</p>	<p>Data Matrix Rectangular On & Rectangular Extended On</p>  <p>M10470_01</p> <p>A4</p>	
<p>Data Matrix Rectangular On & Rectangular Extended Off - Default</p>  <p>M10049_01</p> <p>B1</p>	<p>Data Matrix Rectangular & Rectangular Extended Off</p>  <p>M10048_01</p> <p>B2</p>	<p>Grid Matrix On</p>  <p>M10535_01</p> <p>B3</p>	<p>Grid Matrix Off - Default</p>  <p>M10536_01</p> <p>B4</p>	
<p>All GS1 DataBar On - Default</p>  <p>M10054_01</p> <p>C1</p>	<p>All GS1 DataBar Off</p>  <p>M10055_01</p> <p>C2</p>	<p>GS1 DataBar Limited On</p>  <p>M10056_03</p> <p>C3</p>	<p>GS1 DataBar Limited Off</p>  <p>M10354_02</p> <p>C4</p>	
<p>GS1 DataBar Expanded On</p>  <p>M10059_03</p> <p>D1</p>	<p>GS1 DataBar Expanded Off</p>  <p>M10417_02</p> <p>D2</p>	<p>GS1 DataBar Expanded Stacked On</p>  <p>M10357_02</p> <p>D3</p>	<p>GS1 DataBar Expanded Stacked Off</p>  <p>M10356_02</p> <p>D4</p>	
<p>GS1 DataBar Stacked and GS1 DataBar Stacked Omnidirectional On</p>  <p>M10058_03</p> <p>E1</p>	<p>GS1 DataBar Stacked and GS1 DataBar Stacked Omnidirectional Off</p>  <p>M10353_03</p> <p>E2</p>	<p>GS1 DataBar Omnidirectional and GS1 DataBar Truncated On</p>  <p>M10057_03</p> <p>E3</p>	<p>GS1 DataBar Omnidirectional and GS1 DataBar Truncated Off</p>  <p>M10355_02</p> <p>E4</p>	



















ID-110 Configuration Guide			NOTE: Configuration changes will take effect immediately and be saved to memory.
<p>Han Xin On</p>  <p>M10248_01</p> <p>A1</p>	<p>Han Xin Off - Default</p>  <p>M10249_01</p> <p>A2</p>	<p>Hong Kong 2 of 5 Off - Default</p>  <p>M10078_02</p> <p>A3</p>	<p>Hong Kong 2 of 5 On</p>  <p>M10079_01</p> <p>A4</p>
<p>Int 2 of 5 On - Default</p>  <p>M10060_01</p> <p>B1</p>	<p>Int 2 of 5 Off</p>  <p>M10061_01</p> <p>B2</p>	<p>Int 2 of 5 Checksum Stripped from Result On</p>  <p>M10065_01</p> <p>B3</p>	<p>Int 2 of 5 Checksum On</p>  <p>M10235_01</p> <p>B4</p>
<p>Int 2 of 5 Checksum Off - Default</p>  <p>M10234_01</p> <p>C1</p>	<p>Japan Post On</p>  <p>M10292_02</p> <p>C2</p>	<p>Japan Post Off - Default</p>  <p>M10293_02</p> <p>C3</p>	<p>KIX (Dutch Post) Code On</p>  <p>M10290_02</p> <p>C4</p>
<p>KIX (Dutch Post) Code Off - Default</p>  <p>M10291_02</p> <p>D1</p>	<p>Korean Post On</p>  <p>M10358_01</p> <p>D2</p>	<p>Korean Post Off - Default</p>  <p>M10359_01</p> <p>D3</p>	<p>Maxicode On</p>  <p>M10067_02</p> <p>D4</p>
<p>Maxicode Off - Default</p>  <p>M10066_01</p> <p>E1</p>	<p>Matrix 2 of 5 On</p>  <p>M10069_01</p> <p>E2</p>	<p>Matrix 2 of 5 Off - Default</p>  <p>M10068_01</p> <p>E3</p>	<p>Micro PDF417 On</p>  <p>M10073_01</p> <p>E4</p>
















ID-110 Configuration Guide				NOTE: Configuration changes will take effect immediately and be saved to memory.
<p>Micro PDF 417 Off - Default</p>  <p>M10072_01</p> <p style="text-align: right;">A1</p>	<p>MSI Plessey On</p>  <p>M10076_01</p> <p style="text-align: right;">A2</p>	<p>MSI Plessey Off - Default</p>  <p>M10077_01</p> <p style="text-align: right;">A3</p>	<p>NEC 2 of 5 On</p>  <p>M10082_01</p> <p style="text-align: right;">A4</p>	
<p>NEC 2 of 5 Off - Default</p>  <p>M10083_01</p> <p style="text-align: right;">B1</p>	<p>PDF 417 On - Default</p>  <p>M10070_01</p> <p style="text-align: right;">B2</p>	<p>PDF 417 Off</p>  <p>M10071_01</p> <p style="text-align: right;">B3</p>	<p>Pharmacode On</p>  <p>M10275_02</p> <p style="text-align: right;">B4</p>	
<p>Pharmacode Reverse Barcode Decoding (Right to Left)</p>  <p>M10280_02</p> <p style="text-align: right;">C1</p>	<p>Pharmacode Normal Barcode Decoding (Left to Right)</p>  <p>M10281_02</p> <p style="text-align: right;">C2</p>	<p>Pharmacode Off - Default</p>  <p>M10274_03</p> <p style="text-align: right;">C3</p>	<p>All QR Code On</p>  <p>M10101_02</p> <p style="text-align: right;">C4</p>	
<p>Standard QR Code On - Default</p>  <p>M10095_04</p> <p style="text-align: right;">D1</p>	<p>All QR Code Off</p>  <p>M10351_03</p> <p style="text-align: right;">D2</p>	<p>Straight 2 of 5 On</p>  <p>M10241_01</p> <p style="text-align: right;">D3</p>	<p>Straight 2 of 5 Off - Default</p>  <p>M10240_01</p> <p style="text-align: right;">D4</p>	
<p>Telepen On</p>  <p>M10103_01</p> <p style="text-align: right;">E1</p>	<p>Output Telepen as ASCII</p>  <p>M10521_01</p> <p style="text-align: right;">E2</p>	<p>Output Telepen as Numeric - Default</p>  <p>M10520_01</p> <p style="text-align: right;">E3</p>	<p>Telepen Off - Default</p>  <p>M10104_01</p> <p style="text-align: right;">E4</p>	















ID-110 Configuration Guide			NOTE: Configuration changes will take effect immediately and be saved to memory.
<p>Trioptic On</p>  <p>M10041_01</p> <p>A1</p>	<p>Trioptic - Enable Reverse Order option (Bit 3)</p>  <p>M10446_01</p> <p>A2</p>	<p>Trioptic - Disable Reverse Order option (Bit 3) - Default</p>  <p>M10445_01</p> <p>A3</p>	<p>Trioptic Off - Default</p>  <p>M10040_01</p> <p>A4</p>
<p>UK Plessey On</p>  <p>M10237_02</p> <p>B1</p>	<p>UK Plessey Off - Default</p>  <p>M10236_02</p> <p>B2</p>	<p>UK Royal Mail On</p>  <p>M10294_02</p> <p>B3</p>	<p>UK Royal Mail Off - Default</p>  <p>M10295_02</p> <p>B4</p>
<p>UPC Off</p>  <p>M10106_01</p> <p>C1</p>	<p>UPC On - Default</p>  <p>M10105_01</p> <p>C2</p>	<p>UPC Supplemental On</p>  <p>M10110_01</p> <p>C3</p>	<p>Transmit UPC-A Number System Off</p>  <p>M10478_01</p> <p>C4</p>
<p>UPC Supplemental Off - Default</p>  <p>M10109_01</p> <p>D1</p>	<p>Transmit UPC-A Check Digit On - Default</p>  <p>M10475_01</p> <p>D2</p>	<p>Transmit UPC-A Check Digit Off</p>  <p>M10476_01</p> <p>D3</p>	<p>Transmit UPC-A Number System On - Default</p>  <p>M10477_01</p> <p>D4</p>
<p>Convert UPC-A to EAN-13 On</p>  <p>M10490_01</p> <p>E1</p>	<p>Convert UPC-A to EAN-13 Off - Default</p>  <p>M10489_01</p> <p>E2</p>	<p>UPC-E Expansion On</p>  <p>M10108_01</p> <p>E3</p>	<p>UPC-E Expansion Off - Default</p>  <p>M10107_01</p> <p>E4</p>















ID-110 Configuration Guide			NOTE: Configuration changes will take effect immediately and be saved to memory.
<p>Transmit UPC-E Check Digit On - Default</p>  <p>M10479_01</p> <p style="text-align: right;">A1</p>	<p>Transmit UPC-E Check Digit Off</p>  <p>M10480_01</p> <p style="text-align: right;">A2</p>	<p>Transmit UPC-E Number System On - Default</p>  <p>M10481_01</p> <p style="text-align: right;">A3</p>	<p>Transmit UPC-E Number System Off</p>  <p>M10482_01</p> <p style="text-align: right;">A4</p>
<p>Transmit EAN-8 Check Digit On -Default</p>  <p>M10485_01</p> <p style="text-align: right;">B1</p>	<p>Transmit EAN-8 Check Digit Off</p>  <p>M10486_01</p> <p style="text-align: right;">B2</p>	<p>Convert EAN-8 to EAN-13 On</p>  <p>M10488_01</p> <p style="text-align: right;">B3</p>	<p>Convert EAN-8 to EAN-13 Off -Default</p>  <p>M10487_01</p> <p style="text-align: right;">B4</p>
<p>Transmit EAN-13 Check Digit On - Default</p>  <p>M10483_01</p> <p style="text-align: right;">C1</p>	<p>Transmit EAN-13 Check Digit Off</p>  <p>M10484_01</p> <p style="text-align: right;">C2</p>	<p>Convert Bookland EAN-13 to ISBN On</p>  <p>M10492_01</p> <p style="text-align: right;">C3</p>	<p>Convert Bookland EAN-13 to ISBN Off - Default</p>  <p>M10491_01</p> <p style="text-align: right;">C4</p>
<p>Convert Bookland EAN-13 to ISSN On</p>  <p>M10491_01</p> <p style="text-align: right;">D1</p>	<p>Convert Bookland EAN-13 to ISSN Off - Default</p>  <p>M10493_01</p> <p style="text-align: right;">D2</p>	<p>UPU ID-Tag On</p>  <p>M10360_02</p> <p style="text-align: right;">D3</p>	<p>UPU ID-Tag Off - Default</p>  <p>M10361_02</p> <p style="text-align: right;">D4</p>
<p>USPS Intelligent Mail/IMB/ 4-State CB On</p>  <p>M10286_02</p> <p style="text-align: right;">E1</p>	<p>USPS Intelligent Mail/IMB/ 4-State CB Off - Default</p>  <p>M10287_02</p> <p style="text-align: right;">E2</p>	<p>USPS Planet On</p>  <p>M10284_02</p> <p style="text-align: right;">E3</p>	<p>USPS Planet Off - Default</p>  <p>M10285_02</p> <p style="text-align: right;">E4</p>

ID-110 Configuration Guide			NOTE: Configuration changes will take effect immediately and be saved to memory.	
<p>USPS Postnet On</p>  <p>M10282_02</p> <p style="text-align: right;">A1</p>	<p>USPS Postnet Off - Default</p>  <p>M10283_02</p> <p style="text-align: right;">A2</p>	<p>Grid Matrix & Grid Matrix Inverse Decoding On</p>  <p>M10544_01</p> <p style="text-align: right;">A3</p>	<p>Grid Matrix & Grid Matrix Mirror Decoding On</p>  <p>M10545_01</p> <p style="text-align: right;">A4</p>	
<p>Grid Matrix, Grid Matrix Inverse & Grid Matrix Mirror Decoding</p>  <p>M10546_01</p> <p style="text-align: right;">B1</p>	<p>GoCode & GoCode Inverse Decoding</p>  <p>M10547_01</p> <p style="text-align: right;">B2</p>	<p>GoCode & GoCode Mirror Decoding On</p>  <p>M10548_01</p> <p style="text-align: right;">B3</p>	<p>GoCode, GoCode Inverse & GoCode Mirror Decoding On</p>  <p>M10549_01</p> <p style="text-align: right;">B4</p>	
<p>Code 11 Decoding with one checksum digit checked, and remove checksum from output On</p>  <p>M10550_01</p> <p style="text-align: right;">C1</p>	<p>Keyboard Language Settings</p>		<p>Keyboard Support: French Keyboard Mapping for Apple</p>  <p>M10470_03</p> <p style="text-align: right;">C3</p>	<p>Keyboard Support: USInternational (Universal) Keyboard Mapping for Windows</p>  <p>M10469_01</p> <p style="text-align: right;">C4</p>
<p>English (US) Keyboard Mapping for Windows</p>  <p>M10460_02</p> <p style="text-align: right;">D1</p>	<p>English (UK) Keyboard Mapping for Windows</p>  <p>M10471_01</p> <p style="text-align: right;">D2</p>	<p>Belgian French Keyboard Mapping for Windows</p>  <p>M10461_02</p> <p style="text-align: right;">D3</p>	<p>French Keyboard Mapping for Windows</p>  <p>M10462_02</p> <p style="text-align: right;">D4</p>	
<p>German Keyboard Mapping for Windows</p>  <p>M10463_02</p> <p style="text-align: right;">E1</p>	<p>Japanese Keyboard Mapping for Windows</p>  <p>M10464_02</p> <p style="text-align: right;">E2</p>	<p>Latin American Keyboard Mapping for Windows</p>  <p>M10465_02</p> <p style="text-align: right;">E3</p>	<p>Spanish Keyboard Mapping for Windows</p>  <p>M10472_01</p> <p style="text-align: right;">E4</p>	

ID-110 Configuration Guide			NOTE: Configuration changes will take effect immediately and be saved to memory.
<p>Swiss German Keyboard Mapping for Windows</p>  <p>M10466_02 A1</p>	<p>English Keyboard Mapping for Apple</p>  <p>M10419_02 A2</p>	<p>Keyboard Support: Spanish Keyboard Mapping for Apple</p>  <p>M10424_02 A3</p>	<p>Italian Keyboard Mapping for Apple</p>  <p>M10423_02 A4</p>
<p>German-Swiss Keyboard Mapping for Apple</p>  <p>M10422_02 B1</p>	<p>German Keyboard Mapping for Apple</p>  <p>M10421_02 B2</p>	<p>Russian Keyboard Mapping for Windows</p>  <p>M10418_02 B3</p>	<p>Control Character Input - Ctrl + Character</p>  <p>M10442_01 B4</p>
<p>Control Character Input - Alt + Keypad</p>  <p>M10443_01 C1</p>	<p>Control Character Input -Alt + Leading Zero</p>  <p>M10444_01 C2</p>	<p>Control Character Input - Language - Default</p>  <p>M10441_01 C3</p>	<p>Data Encoding: Raw ASCII to Keyboard XML File Lookup - Default</p>  <p>M10514_01 C4</p>
<p>Data Encoding: UTF8 to Unicode Codepoint - Alt Sequences for Windows</p>  <p>M10515_01 D1</p>	<p>Reader (Legacy) - US English Keyboard Mapping - with Leading 0 for Non Printable ASCII - Default</p>  <p>M10411_01 D2</p>	<p>Operating System Settings</p>	<p>Alternative Operating System (Linux/Mac) On</p>  <p>M10123_02 D4</p>
<p>Alternative Operating System (Linux/Mac) Off - Default</p>  <p>M10122_02 E1</p>	<p>USB Settings (Non-Batch Mode)</p>	<p>Modem - USB Keyboard Communication Mode - Default</p>  <p>M10189_01 E3</p>	<p>USB Downloader Mode</p>  <p>M10804_02 E4</p>

ID-110 Configuration Guide			NOTE: Configuration changes will take effect immediately and be saved to memory.
Modem - USB HID POS  M10007_03 A1	Modem - USB Virtual COM Mode  M10427_01 A2	USB Settings	Reader - USB Virtual COM CDC Raw Mode  M10438_01 A4
RS232 Settings (for use with CodeXML M3 Modem Only)	RS232 Communication Mode  M10242_01 B2	RS232 Interface - 9600 Baud Rate - Default  M10243_01 B3	RS232 Interface - 19200 Baud Rate  M10244_01 B4
RS232 Interface - 38400 Baud Rate  M10245_01 C1	RS232 Interface - 57600 Baud Rate  M10246_01 C2	RS232 Interface - 115200 Baud Rate  M10247_01 C3	Intentionally Blank C4
RS232 Settings	Reader - Enable RS232 OPOS/JPOS  M10467_01 D2	Reader Feedback Settings	Beep On Vibrate On - Default  M10140_01 D4
Beep Off Vibrate Off  M10143_02 E1	Beep Off Vibrate On  M10141_02 E2	Beep On Vibrate Off  M10142_01 E3	Disable AES Encryption - Default  M10526_01 E4

ID-110 Configuration Guide			NOTE: Configuration changes will take effect immediately and be saved to memory.
<p>Beep Volume 100% - Default</p>  <p>M10197_01</p> <p>A1</p>	<p>Beep Volume 67%</p>  <p>M10196_01</p> <p>A2</p>	<p>Beep Volume 33%</p>  <p>M10195_01</p> <p>A3</p>	<p>Beep Volume 0%</p>  <p>M10194_01</p> <p>A4</p>
<p>Scan Delay Settings</p>	<p>Duplicate Scan Disabled - Default</p>  <p>M10144_01</p> <p>B2</p>	<p>1 Second Duplicate Scan Delay</p>  <p>M10145_01</p> <p>B3</p>	<p>2 Second Duplicate Scan Delay</p>  <p>M10146_01</p> <p>B4</p>
	<p>3 Second Duplicate Scan Delay</p>  <p>M10147_01</p> <p>C1</p>	<p>5 Second Duplicate Scan Delay</p>  <p>M10148_01</p> <p>C2</p>	<p>10 Second Duplicate Scan Delay</p>  <p>M10149_01</p> <p>C3</p>
<p>1 Hour Duplicate Scan Delay</p>  <p>M10151_01</p> <p>D1</p>	<p>1 Day Duplicate Scan Delay</p>  <p>M10152_01</p> <p>D2</p>	<p>Power Settings</p> <p>Miscellaneous Settings</p>	
<p>Power Off in 2 Hour</p>  <p>M10317_01</p> <p>E1</p>	<p>Power Off in 4 Hours</p>  <p>M10318_01</p> <p>E2</p>		

ID-110 Configuration Guide			NOTE: Configuration changes will take effect immediately and be saved to memory.
<p>Read High Density Field Only</p>  <p>M10183_01</p> <p>A1</p>	<p>Read Wide Field Only</p>  <p>M10182_01</p> <p>A2</p>	<p>Enable AES Encryption</p>  <p>M10525_01</p> <p>A3</p>	<p>Bottom Button Take Picture</p>  <p>M10540_01</p> <p>A4</p>
<p>Top Button Take Picture</p>  <p>M10539_01</p> <p>B1</p>	<p>Locked Reader Accept Host Commands - Default</p>  <p>M10527_01</p> <p>B2</p>	<p>Locked Reader Reject Host Commands</p>  <p>M10528_01</p> <p>B3</p>	<p>Allow Wireless Switching on a Locked Reader - Default</p>  <p>M10533_01</p> <p>B4</p>
<p>Prevent Wireless Switching on a Locked Reader</p>  <p>M10534_01</p> <p>C1</p>	<p>Reader/Modem Command Settings</p>		<p>Reader ID and Firmware Version</p>  <p>M10157_01</p> <p>C3</p>
			<p>Modem ID and Firmware Version</p>  <p>M10158_01</p> <p>C4</p>
<p>Reader Text Commands On</p>  <p>M10137_01</p> <p>D1</p>	<p>Reader Text Commands Off - Default</p>  <p>M10136_01</p> <p>D2</p>	<p>Reset, Clear and Save Reader Settings</p>	
			<p>Reset Reader to RF Factory Defaults</p>  <p>M10001_03</p> <p>D4</p>
<p>Clear All JavaScript Rules</p>  <p>M10139_02</p> <p>E1</p>	<p>Clear All Stored Data and Images</p>  <p>M10138_02</p> <p>E2</p>	<p>Save All Reader Settings - Default</p>  <p>M10159_01</p> <p>E3</p>	<p>Reboot Reader</p>  <p>M10296_01</p> <p>E4</p>

Hinweise zu Open Source Software / Notes on open source software

OPEN SOURCE LIZENZEN

Dieses di-soric Produkt enthält Open Source Software von verschiedenen Entwicklern, die unterschiedlichen Lizenzen unterliegen, z.B. der General Public License in allen Versionen.

Für di-soric Produkte, die der General Public License in ihrer jeweiligen Fassung unterliegen, gilt Folgendes:

Es ist freie Software: Sie können sie gemäß den Bedingungen der GNU General Public License verwenden, die von der Free Software Foundation veröffentlicht wird.

Der folgende Haftungsausschluss gilt für Softwarekomponenten, die der General Public License oder der Lesser General Public License in ihren jeweiligen Versionen unterliegen:

HAFTUNGSAUSSCHLUSS

Open Source Software wird in der Hoffnung verbreitet, dass sie nützlich ist, jedoch ohne jegliche Gewährleistung, auch ohne die implizite Garantie der Handlungsfähigkeit oder Eignung für einen bestimmten Zweck.

Weitere Einzelheiten finden Sie in den entsprechenden Lizenzen.

Die Verantwortung von di-soric für di-soric Produkte bei produktspezifischer Software bleibt von dem vorstehenden Haftungsausschluss unberührt.

URHEBERRECHTSHINWEIS

Bitte beachten Sie, dass wir Open Source Software zusammen mit diesem Produkt und/oder dieser Produktfirmware verwenden (im Folgenden nur „Produkt“).

Die Open Source Software-Lizenzen werden von den jeweiligen Rechteinhabern vergeben. Die Open Source Lizenzen haben Vorrang vor allen anderen Lizenzinformationen in Bezug auf die jeweilige Open Source-Software, die im Produkt enthalten ist, einschließlich, aber nicht beschränkt auf den Endbenutzer-Softwarelizenzvertrag.

Die neuesten Informationen zur Lizenzvereinbarung für Ihr Produkt sind auf der Website des jeweiligen Produkts bzw. im Download-Bereich in der jeweiligen zip-Datei integriert (www.di-soric.com).

OPEN SOURCE LICENSES

This di-soric product contain Open Source Software from various developers which is subject to different licenses e.g. the General Public License in all versions. For di-soric products which are subject to the General Public License in their respective versions the following applies:

It is free software: you can use it under the terms of the GNU General Public License as published by the Free Software Foundation.

The following disclaimer applies to the software components that are subject to the General Public License or the Lesser General Public License in their respective versions:

WARRANTY DISCLAIMER

Open Source Software is distributed in the hope that it will be useful, but without any warranty; without even the implied warranty of merchantability or fitness for a particular purpose. See the applicable licenses for more details.

The responsibility of di-soric for di-soric products, in the case of product-specific software, remains unaffected by the above disclaimer.

COPYRIGHT NOTICE

Please note we use Open Source Software along with this product and/or this product firmware (in the following just "product").

The Open Source Software licenses are granted by the respective right holders. And the Open Source licenses prevail all other license information with regard to the respective Open Source Software contained in the product, including but not limited to End User Software Licensing Agreement.

The latest information on the license agreement for your product are integrated in the website of the respective product or in the zip-file at the download area (www.di-soric.com).

For source code which is licensed under any version of the GNU General Public License (GPL) or the GNU LGPL you may obtain the complete corresponding source code of the GPL software from us by sending a written request to:

opensource@di-soric.com. Please write the following information in your request (i) the name of the covered binary, (ii) the di-soric product code and the version number, (iii) your complete contact information.

This offer is valid for at least three years (from the date you received the GPL/LGPL covered code).

SOLUTIONS. CLEVER. PRACTICAL.

di-soric GmbH & Co. KG | Steinbeisstrasse 6 | 73660 Urbach | Germany
Phone +49 71 81 98 79-0 | Fax +49 71 81 98 79-179 | info@di-soric.com

www.di-soric.com